



Excessive penetration.

A lighter density in the centre of the width of the weld image, either extended along the weld or in isolated circular drops.